



USER MANUAL

UNOPT



UNOPT Series



UNBPT Series



UNSPT Series

1 Function Definition .. 1 - 2

- 1.1 - Input Voltage Range
- 1.2 - Inrush Current
- 1.3 - Overcurrent Protection
- 1.4 - Overvoltage Protection
- 1.5 - Output Ripple & Noise
- 1.6 - Isolation
- 1.7 - Reducing Standby Power
- 1.8 - Output Voltage Adjustment Range

3 Instructions 8-9

- 3.1 - Series Operation & Parallel Operation
- 3.2 - External Use Of Capacitor On Output Side

2 Installation 3 - 7

- 2.1 - Installation Method
- 2.2 - Mounting Screw
- 2.3 - Ground
- 2.4 - Mounting Direction and Method
- 2.5 - Derating Curve & Temperature
- 2.6 - Temperature Measurement Point

4 Life Expectancy & Warranty .. 10

5 Cautions 11

1. Function Definition

1.1 - Input Voltage Range

- The range is from 85VAC to 264VAC. In cases that comply with safety standard, input voltage range is 100VAC to 240VAC (50/60Hz). Appendix 8 of PSE comply with 100~240VAC 50/60 Hz . When using with DC input, in order to provide safe protection when the power fails, please choose a DC power supply product with protection function or install DC fuse for protection. For detail information please contact us.
- If input doesn't fall within above range, please note that it may cause operation that does not meet the specifications 、 repeated starting or fail. If you need the square waveform input voltage which is commonly used in UPS and inverters, please contact us.
- When the input voltage changes suddenly, the output voltage accuracy might exceed the specification. If the restart time of the short interruption power failure is less than 3 seconds, perform a thorough evaluation.
- Supports instantaneous input voltage sag, the output load reference is as follows: doesn't support Input Voltage AC 100VAC->50VAC , support input voltage AC 200VAC->100VAC, output load 100%.

1.2 - Inrush Current

- An inrush current limiting circuit is built-in.
- If using a switch or similar device on the input side, please select one that can withstand an input inrush current.
- To prevent inrush current, please wait more than 3 seconds before turning on.

1.3 - Overcurrent Protection


- An overcurrent protection circuit is built-in (operating above 101% of the peak current.) If the overcurrent abnormality is eliminated, please connect the power again and the output voltage will return to normal.
- Intermittent Current Mode:
When the output voltage drops at overcurrent, the average output current is reduced by intermittent current mode. If the output voltage drops, the output will stutter and reduce (lower) the average current.
- Please avoid use in short-circuit or over-current mode for long-term.

1.4 - Overvoltage Protection

- An overvoltage protection circuit is built-in. If the overvoltage protection circuit is activated, turn off the input voltage and turn on the AC input again to recover the output voltage.
- UNOPT3075 An overvoltage protection circuit is built in. If the overvoltage protection circuit is activated, turn off the input voltage. After one minute, turn the input voltage back on to recover the output voltage.
The recovery time may vary depending on the input voltage at the time of activation.
- Caution : When a voltage higher than the rated voltage which is applied to the output terminal from the outside, it may cause fail or malfunction, so please avoid this action.
When using motor load... etc., please contact us.

1.5 - Output Ripple & Noise

- Output ripple noise may be influenced by measurement environment, the below measuring method is recommended as the picture 1.5.1
- If the output ripple & noise are test by an oscilloscope, the power supply generates magnetic flux that passes through the GND line loop of the measuring probe tip, ripple & noise might not measure correctly. In addition, please keep sufficient distance between input and output wires in order to reduce the influence of the above magnetic flux when using the power supply, and spiral wire type is recommended.



1.5.1 Example of measuring output ripple & noise

1.6 - Isolation

- When conducting the inspection, gradually increase the voltage. After the test is completed, please also slowly decrease the voltage.
- When choosing -xR product, please short-circuit the output terminal, 5V output terminal and RC terminal when testing between input-output, input-FG and output-FG.

1.7 - Reducing Standby Power

- There is a built-in function to reduce power consumption during standby. At light load, the internal switch element is operated in burst mode to reduce switching power supply loss. This may cause the specifications of ripple & noise to change.


1.8 - Output Voltage Adjustment Range

- The output voltage can be adjusted through a variable resistor of the output voltage.
- To increase an output voltage, turn the variable resistor clockwise.

2.Installation


2.1 - Installation Method

■ Open Frame




2.1.1 UNOPT3050 | The installation distance of open frame

■ Open Frame



2.1.2 UNOPT3075 | The installation distance of open frame

■ Enclosed Type




2.1.3 The picture of power supply with case

- For safety reasons, please ensure the mounted device is kept at a safety distance as below at all sides from other components and equipments.

- Open frame ≥ 8 mm from primary side ≥ 4 mm from secondary side.
- Enclosed Type ≥ 4 mm


- There is a possibility that it is not possible to cool enough when the power supply is used in the sealing up space as showing as below picture.



2.1.4 The picture of power supply with case

2.2 - Mounting Screw

- Please use M3 screws for mounting.
- The shaded area in picture 2.2.1 below is the range of ground.
- Please refer to the diagram below to ground, fix the mounting holes and connect the mounting holes to the ground.
- Please note that the standard shock resistance specifications are based on using 8mm height.
- The copper foil for PCB grounding is 8*8mm.




2.2.1 Mounting hole

2.3 - Ground

- The below three methods can be used:
 - ① FG pin of CN1 connected to ground.
 - ② Mounting holes connected to ground.
 - ③ The system case connected to ground.

2.4 - Mounting Direction and Method


- The installation as below, (A) is recommended. (B)~(F) are also applicable. Please do not install with other directions.




2.4.1 Mounting direction

- Do not twist or bend the printed circuit board since SMD components were soldered on it.
- All mounting holes must be fixed.
- Please install the printed circuit board parallel to the mounting surface.
- Do not drop the product.

■ Forced Cooling




2.4.2 UNOPT3050 | The schematic diagram of air flow




2.4.3 UNOPT3075 | The schematic diagram of air flow

2.5 - Derating Curve & Temperature



2.5.1 Mounting direction


■ Mounting direction output derating curve



2.5.2 UNOPT3050
Mounting direction output derating curve


■ Input voltage & derating

It requires derating while input voltage lower than 90VAC.



2.5.3 UNOPT3050 | Input derating curve


■ Mounting direction output derating curve



2.5.4 UNOPT3075
Mounting direction output derating curve

■ Input voltage & derating


It requires derating while input voltage lower than 90VAC.



2.5.5 UNOPT3075 | Input derating curve

2.6 - Temperature Measurement Point

- When using equipment must consider the power supply to cooling.
- The picture below shows the relationship between the upper temperature limitation and load of points (A) and (B). In order to allow the entire power supply to have sufficient ventilation, it is necessary to consider the conditions of the wind, and ensuring that the temperatures at points (A) and (B) must be below the specified upper limit.
- When operating at the maximum temperature limit of points (A) and (B), the life expectancy is more than 3 years.
- Points (A) and (B) are conductive parts. When measuring temperature, be careful to electric shock and leakage. Please contact us for details.
- Point A・B are as below.
- Please refer to the pictures for setting method & conditions.




Point A、Point B are the temperature measurement point

2.6.1 UNOPT3050 | Temperature measurement point

Mounting Method	Cooling Method	Load factor	Max temperature	
			Point A(°C)	Point B(°C)
A	Convection	75% < ϕ ≤ 100%	82	73
		50% < ϕ ≤ 75%	88	79
		0% < ϕ ≤ 50%	94	85
B	Convection	75% < ϕ ≤ 100%	82	73
		50% < ϕ ≤ 75%	88	79
		0% < ϕ ≤ 50%	94	85
C	Convection	75% < ϕ ≤ 100%	82	73
		50% < ϕ ≤ 75%	88	79
		0% < ϕ ≤ 50%	94	85
D	Convection	75% < ϕ ≤ 100%	82	73
		50% < ϕ ≤ 75%	88	79
		0% < ϕ ≤ 50%	94	85
E	Convection	75% < ϕ ≤ 100%	82	73
		50% < ϕ ≤ 75%	88	79
		0% < ϕ ≤ 50%	94	85
F	Convection	75% < ϕ ≤ 100%	82	73
		50% < ϕ ≤ 75%	88	79
		0% < ϕ ≤ 50%	94	85
A	Forced air	70% < ϕ ≤ 100%	78	73
		0% < ϕ ≤ 70%	78	73
B	Forced air	70% < ϕ ≤ 100%	78	73
		0% < ϕ ≤ 70%	78	73
C	Forced air	70% < ϕ ≤ 100%	78	73
		0% < ϕ ≤ 70%	78	73
D	Forced air	70% < ϕ ≤ 100%	78	73
		0% < ϕ ≤ 70%	78	73
E	Forced air	70% < ϕ ≤ 100%	78	73
		0% < ϕ ≤ 70%	78	73
F	Forced air	70% < ϕ ≤ 100%	78	73
		0% < ϕ ≤ 70%	78	73

2.6.3 UNOPT3050

Temperature measurement point and capacitor temperature



Point A、Point B are the temperature measurement point

2.6.2 UNOPT3075 | Temperature measurement point

Mounting Method	Cooling Method	Load factor	Max temperature	
			Point A(°C)	Point B(°C)
A	Convection	75% < ϕ ≤ 100%	84	75
		50% < ϕ ≤ 75%	75	69
		0% < ϕ ≤ 50%	68	65
B	Convection	75% < ϕ ≤ 100%	82	74
		50% < ϕ ≤ 75%	78	68
		0% < ϕ ≤ 50%	67	64
C	Convection	75% < ϕ ≤ 100%	80	76
		50% < ϕ ≤ 75%	73	67
		0% < ϕ ≤ 50%	69	63
D	Convection	75% < ϕ ≤ 100%	78	74
		50% < ϕ ≤ 75%	72	70
		0% < ϕ ≤ 50%	69	68
E	Convection	75% < ϕ ≤ 100%	77	75
		50% < ϕ ≤ 75%	74	71
		0% < ϕ ≤ 50%	68	66
F	Convection	75% < ϕ ≤ 100%	87	83
		50% < ϕ ≤ 75%	82	80
		0% < ϕ ≤ 50%	77	72
A	Forced air	70% < ϕ ≤ 100%	83	77
		0% < ϕ ≤ 70%	76	72
B	Forced air	70% < ϕ ≤ 100%	84	74
		0% < ϕ ≤ 70%	80	69
C	Forced air	70% < ϕ ≤ 100%	81	76
		0% < ϕ ≤ 70%	77	70
D	Forced air	70% < ϕ ≤ 100%	78	75
		0% < ϕ ≤ 70%	76	71
E	Forced air	70% < ϕ ≤ 100%	78	69
		0% < ϕ ≤ 70%	71	66
F	Forced air	70% < ϕ ≤ 100%	85	80
		0% < ϕ ≤ 70%	76	71

2.6.4 UNOPT3075


Temperature measurement point and capacitor temperature

3. Instructions

3.1 - Series Operation / Parallel Operation

■ Series Operation


- Please note that the output current must less or equal to rated current ' ' and cannot exceed the rated current. The example of series operation is shown in picture 3.1.1
- The rated current of the bypass diode must more than or equal to the load current, and the reverse rated withstand voltage must be higher than the power supply output voltage.



3.1.1 The example of series operation & parallel operation

■ Parallel Operation/Long-term Operation


- Can be used as a backup power to connect.
- The output voltage and output power of the power supply should comply with the specification values. The connection for long-term operation are shown as picture 3.1.2
- Slightly differences in output voltage may cause unbalanced of I1 and I2 values. Make sure that the value of I3 does not exceed the rated current of a power supply.
 $I_3 \leq \text{Rated current}$.



3.1.2 The example of parallel operation/loge-term operation

3.2 - External use of capacitor on output side

- The size of the additional capacitor, ESR, ESL and wiring inductance may cause resonance and ripples.
- If the external capacitor capacity is too large, the output voltage may not start normally.
Please refer to pictures for the maximum allowable external capacitor capacity.



3.2.1 The example of connect an external capacitor to the output

Output Voltage	Capacitance(μF)
12V	5000 μF
15V	5000 μF
24V	2000 μF
48V	500 μF

3.2.2 UNOPT3050
External use of load capacitor on output side

Output Voltage	Capacitance(μF)
12V	10000 μF
15V	8000 μF
24V	6000 μF
48V	5000 μF

3.2.3 UNOPT3075
External use of load capacitor on output side

4. Life Expectancy / Warranty

UNOPT3050

■ Life Expectancy

Mounting Method	Cooling Method	Average ambient temperature(year)	Life Expectancy	
			$10 \leq 75\%$	$75\% \leq 10 \leq 100\%$
A	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
B	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
C	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
D	Convection	Ta = 35°C or less	5years	5years
		Ta = 45°C	5years	3years
E	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
F	Convection	Ta = 30°C or less	5years	5years
		Ta = 40°C	5years	3years
A,B,C, D,E,F	Forced air	Ta = 60°C	5years	3years

■ Warranty

Mounting Method	Cooling Method	Average ambient temperature(year)	Warranty	
			$10 \leq 75\%$	$75\% \leq 10 \leq 100\%$
A	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
B	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
C	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
D	Convection	Ta = 35°C or less	5years	5years
		Ta = 45°C	5years	3years
E	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
F	Convection	Ta = 30°C or less	5years	5years
		Ta = 40°C	5years	3years
A,B,C, D,E,F	Forced air	Ta = 60°C	5years	3years

4.1.1 Expectancy

4.1.2 Warranty

UNOPT3075

■ Life Expectancy

Mounting Method	Cooling Method	Average ambient temperature(year)	Life Expectancy	
			$10 \leq 75\%$	$75\% \leq 10 \leq 100\%$
A	Convection	Ta = 30°C or less	5years	3years
		Ta = 40°C	5years	3years
B	Convection	Ta = 30°C or less	5years	5years
		Ta = 40°C	5years	3years
C	Convection	Ta = 35°C or less	5years	5years
		Ta = 45°C	5years	3years
D	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
E	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
F	Convection	Ta = 20°C or less	5years	5years
		Ta = 30°C	5years	3years
A,B,C, D,E,F	Forced air	Ta = 60°C	5years	3years

■ Warranty

Mounting Method	Cooling Method	Average ambient temperature(year)	Warranty	
			$10 \leq 75\%$	$75\% \leq 10 \leq 100\%$
A	Convection	Ta = 30°C or less	5years	3years
		Ta = 40°C	5years	3years
B	Convection	Ta = 30°C or less	5years	5years
		Ta = 40°C	5years	3years
C	Convection	Ta = 35°C or less	5years	5years
		Ta = 45°C	5years	3years
D	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
E	Convection	Ta = 40°C or less	5years	5years
		Ta = 50°C	5years	3years
F	Convection	Ta = 20°C or less	5years	5years
		Ta = 30°C	5years	3years
A,B,C, D,E,F	Forced air	Ta = 60°C	5years	3years

4.1.3 Expectancy

4.1.4 Warranty

5. Cautions

- If there are any differences from the listed here, then based on the individual .
 - This product is an open frame power supply. When using it, please make sure that no conductive objects fall into the printed circuit board.
 - When the low load, high voltage may remain inside the power supply for several minutes after the input power is turned off. Please be careful not to touch it.
 - Do not touch this product immediately while it is power on or off, as it may result in burns or electric shock.
 - The SMD components were soldered on the printed circuit board. Twisting or bending the printed circuit board may cause product failure, so please operate with caution. When handling items, hold the board by its edges and avoid touching components.
 - Do not modify, disassemble or remove covers. Otherwise it may cause electric shock or fail. The manufacturer will not assume any responsibility after modification, alteration or disassembly.
 - Do not use this product under abnormal conditions and special environments, such as exposure under the sunlight, condensation, water, rain, strong electromagnetic fields or places and environments with corrosive gases (hydrogen sulfide, sulfur dioxide, etc.).
 - Do not use or store this product in an environment where moisture or condensation. It may result in electric shock or fire.
 - The noise of terminal voltage, noise intensity, and immunity are the results under the standard measurement conditions of UNIFIVE's products. The equipment's installation and wiring conditions may not meet standards. Please make a thorough evaluation of actual equipment before using the product. Please be sure to conduct the necessary testing for final product.
 - Make sure the input/output terminals and each signal terminal are wired correctly, as described in the user manual. Use this product within the specifications of the voltage, output current, output power, ambient temperature and humidity. Using the product beyond specifications may result in product damage and avoid overloading this product.
 - Use the shortest and thickest wires as possible.
 - When wiring the input and output terminals, disconnect power from the input terminals.
 - If the built-in fuse blows, do not replace the fuse and continue to use the device. An abnormality may have occurred within the device.
 - If the product hasn't been used for a long time, the leakage current in the aluminum electrolytic capacitor will increase, reducing the life expectancy. Applying voltage on aluminum electrolytic capacitor allows the electrolyte to have a repairing effect and the leakage current may be reduced.
 - If the product is stored for more than one year, it should be power on for at least 30 minutes without load before use.
 - The contents of the product catalog and user manual are change without prior notice. When using the product, please refer to the latest catalog and user manual.
- Disclaimer
 - 1.Regardless of whether within the free warranty period or outside the free warranty period, damage caused by reasons that cannot be attributed to our company, damage caused by the company's products, loss of opportunity and loss of profits caused by malfunction, as well as damage caused by special circumstances, whether foreseeable by our company or not. For special condition, UNIFIVE is not responsible for secondary damage, accident compensation, or damage caused to other products or other work.
 - 2.Our products are designed for general industrial equipment and are not suitable for the equipment which acquire highly safety applications (requiring highly reliability and safety, if lack of above characteristics may directly endanger life or health). Although we strive to improve quality and reliability, malfunctions or misoperations may occasionally occur. Therefore, when use our products for high-safety purposes, be sure to adopt necessary fail-safe designs to ensure safety. Please note that UNIFIVE is not responsible for any claims from your or a third party's use of our products for high safety purposes.